微波爐 MICROWAVE OVEN

 \bigcirc

R-222F

使用説明書及烹飪書 OPERATION MANUAL AND COOKBOOK



目録 頁數	CONTENTS Page
操作說明	Operation Guide
警告 C-1	Warning E-1
特別注意事項C-2	Special Notes E-2
安裝事宜	Installation Instructions E-3
各部位名稱 C-3	Oven Diagram E-3
控制板 C-4	Control Panel E-4
微波烹調技巧	Microwave Cooking Techniques E-5
控制板指南	Operation of Control Panel E-6
示範功能(兒童安全鎖)C-7	Demonstration Mode (Child Lock) E-7
清洗及注意事項	Care and Cleaning E-8
維修前的檢查	Service Call Check E-8
規格 C-8	SpecificationsE-8
<u>烹飪書專欄</u>	Cookbook Section
烹調器具指南 ①	Cookware and Utensil Guide ①
米飯烹調指南 ①	Rice Menu Chart ①
解凍項目一覽表 ②	Defrost Chart 2
食譜 ③-⑭	Recipes 3-4

警告

重要安全須知:請細心閱讀,並儲存作將來參考之用。

- 1. 為防止意外發生,請注意並遵守下列事項:
 - a. 切勿讓食品烹調過度。
 - b. 烹調食品前,先拆去綁紮包裝袋的金屬線。
 - c. 切勿用微波爐來加熱食油或油炸食品,因為油溫會變得很高而難以控制。
 - d. 每次使用後,應先以濕布,再以乾布除去噴濺於波導管罩及爐内的食物及油垢。積存在微波 爐内部的油污可能引致黑煙或起火。
 - e. 烹調中發生冒煙或起火現象時,請不要立刻拉開爐門,應先停止操作及拔除電源線,或將保 險絲或電流斷路器之開關關閉。
 - f. 使用即棄容器如塑膠、紙或其他可燃燒材料作烹調時,應小心注意爐內情況。
- 2. 為防止烹調食品的爆濺,請遵守下列事項:
 - a. 切勿用密封容器進行烹調。如帶有瓶蓋或奶嘴的奶瓶均屬密封容器。
 - b. 烹調時間切勿過長。
 - C. 加熱液體時,一定要用闊口容器。
 - d. 待烹調後最少20秒才取出食物,以免煮滾的液體爆濺。
 - e. 烹調前及烹調中將液體攪拌,盛載食物的器皿,或放匙羹或其他器具於器皿内時,應特別小心處理。
- 3. 本微波爐僅可作為家庭烹調使用,並僅應用於食物和飲料之加熱、烹調和解凍。 不適合作為商業或實驗室之用。
- 4. 微波爐門夾有雜物或沒有關閉好時,切勿加以使用。
- 5. 請切勿試圖自行更改或維修此微波爐。若由未接受過聲寶公司正式訓練之合格技術人員進行任何服務或維修,是非常危險的。因維修時如需要開啓微波爐蓋,可能會導致微波洩漏。
- 6. 微波爐發生故障時,應先請聲寶之合格技術人員加以檢查修理後才繼續使用。請注意爐門必須可以關緊及沒有以下故障:
 - (1) 爐門(彎曲、扭翹) (2) 鉸鏈和鎖扣(破斷、鬆脫) (3) 爐門密封襯墊和襯墊層表面
- 7. 從微波爐内取出食物時,請小心不要讓器皿,衣服或裝飾物被微波爐門鎖鈎到。
- 8. 電源供應線破損時,必須更換一條聲寶維修中心所認可或提供之電源線,並必須由接受過聲寶公司訓練之合格技術人員更換。
- 9. 請切勿將電源線壓於微波爐之下、擱置於發熱體表面或掛於銳利的物品上,以冤受損壞。
- 10. 如果爐箱内照明燈發生故障,請與聲寶維修中心聯絡。
- 11. 烹調結束後欲取出爐内食品時,務請戴用烹調手套,以免燙傷;並應小心揭蓋,以免蒸氣灼傷 手或面部 。
- 12. 烹調後小心揭蓋,以冤蒸氣灼傷手或面部。
- 13. 為防止轉盤受損壞,請遵守下列事項:
 - a. 用水清洗轉盤時,應先待轉盤冷卻。
 - b. 切勿置滾熱食品或熾熱容器於冷卻的轉盤之上。
 - c. 切勿置冰冷食品或容器於熾熱的轉盤之上。
- 14. 請切勿將任何物件遮蓋外殼或放於爐頂上。
- 15. 請確保烹調器皿於烹調時不會與爐箱內壁碰觸。
- 16. 請勿使用微波爐作任何貯藏食物或物件用途。
- 17. 在沒有正確指引及監察下,請勿讓年幼兒童或殘弱人士自行操作微波爐。
- 18. 請務必清楚詳細地對兒童講解一切安全指引及不適當使用此爐的危險性,不可讓兒童於沒有成人監察下自行操作微波爐。
- 19. 請勿讓兒童把微波爐當作玩具玩耍。

特別注意事項

	要求事項	忌諱事項
蛋類、水果、 果仁、種子、 蔬菜、香腸和牡 蠣(蠔)	* 烹調蛋類、牡蠣等食品時,需於蛋黃、蛋白或牡蠣表面刺數孔,以免烹調加熱時爆裂。 * 烹調馬鈴薯、蘋果、美國南瓜、熱狗、香腸及牡蠣等時,戳其皮數孔,讓烹調加熱時內部水蒸氣能逸出。	* 烹調或加熱帶殼蛋類。(若「爆裂」,可能損壞微波爐或令自己受傷。) * 為帶殼熟蛋類加熱。 * 過度加熱牡蠣(蠔)。 * 為帶殼果仁或種子類加熱。
爆玉米花	* 用微波爐爆玉米花時,必須使用微波爐爆玉米花專用袋。 * 聽到爆玉米花聲已減慢到1-2秒一次時,應停止繼續烹調,以免過火。	* 用普通的爆玉米花袋或玻璃罐來爆玉 米花。 * 用微波爐爆玉米花專用袋爆玉米花 時,設定的烹調時間過於所需時間。
嬰兒食品	* 轉盛嬰兒食品於微波爐烹調容器中, 小心加熱之。檢查適當的溫度,以免 灼傷。 * 直接加熱盛於嬰兒奶瓶中的牛奶時, 必須揭去其旋蓋和奶嘴。加熱後,套 上奶嘴,充份搖勻,達至適當溫度 後,才餵嬰兒食用。	* 加熱即棄式瓶罐。 * 把奶瓶加熱過度,故請只加熱至溫熱的程度。 * 用帶有奶嘴的奶瓶加熱。 * 直接用盛載嬰兒食品的瓶罐加熱。
一般食品	* 烹調有餡料的食品後,請分斷切開, 讓蒸氣逸出,以防止餘熱使之繼續烹調。 * 加熱湯類飲料時,須用深底容器,以 防湯類飲料濺出。	* 盛食品於玻璃罐或密封容器來加熱烹調。 * 以微波爐來煎炸食品。 * 用微波爐烘烤木頭、草類、或潮濕紙張。 * 無食品狀態下操作微波爐。
液體(飲料)	* 如要煮滾或烹調液體,請參照C-1頁 之警告,以冤引起爆炸或爆濺。	* 超過所建議的烹調時間。
罐頭食品	* 把罐頭食品取出及放於容器内。	* 把整個罐頭加熱或烹調。
香腸卷、餡餅、 聖誕布丁	*屬高糖份及高脂肪含量的食品。因此必須按"烹調指南"中的設定時間加以烹調。	* 烹調過份,以致冒煙起火。
肉類	* 使用耐微波碟或盤,以收集及積聚肉 類之汁液。	* 直接置肉塊於轉盤上烹調。
容器	* 使用前先確認該容器能否適用於微波 烹調。	* 使用金屬容器進行微波烹調。金屬反射微波能引起火花現象。
鋁箔紙(錫紙)	* 用鋁箔紙來包裹食品薄細部份,以免烹調過度。 * 注意火花產生。所以儘可能減少使用鋁箔紙,及應與爐之内壁保持距離。	* 鋁箔紙的使用過多。 * 用鋁箔紙包裹的食品過於靠近爐箱內 壁,以致火花產生,損壞微波爐。

安裝事官

1. 將微波爐內的包裝物件及爐門之宣傳標貼(若附有)全部拆去,認真檢查是否有損壞之處,必要時進行修理。

例如:檢查爐門的安裝有否偏差,爐門周圍的密封襯墊有否損壞或微波爐內及爐門上是否有凹痕等。若發現有任何損壞之處,請立刻與聲寶維修中心聯絡,接受維修人員的檢查與修理後,才可使用本微波爐。

- 2. 檢查本微波爐是否帶有下述附件:
 - 1) 轉盤 2) 轉盤旋轉架 3) 使
 - 3) 使用說明書(連烹飪書專欄)
- 3. 先將轉盤旋轉架置於微波爐內,然後再將轉盤置於轉盤旋轉架上,並與聯接器扣好。切勿於未置轉盤及其旋轉架時,強行使用微波爐。
- 4. 請勿將微波爐安裝在高溫或潮濕的地方,例如焗爐附近。而於安裝微波爐時,亦須注意避冤堵塞或 掩蓋微波爐的通風口。

從爐頂以上之空間應有最少十五厘米,以便空氣流通。

微波爐的設計不適宜嵌入牆壁或櫥櫃内。

- 5. 由於用戶未遵照正確的電源接駁指示而引致微波爐損壞或其他不良後果時,廠方及經銷商概不負責。本微波爐所使用的交流電源的電壓和頻率必須與微波爐背面的標牌所示一致。
- 6. 本微波爐的地線必須接地:


重點

電源線中導線按照以下方式標色: 緑黃色: 地線

藍 色: 中線 褐 色: 火線

本微波爐電源線中導線的色標可能與閣下所用的插頭(或插座)上的色標不相同,屆時請按以下規則操作: 綠黃色的導線必須與以下幾種插頭(插座)之一相接:標有E字母、帶有÷符號、色標為綠色或黃綠色。 藍色的導線必須與標有N字母或藍色的插頭(或插座)相接。 褐色的導線必須與標有L字母或褐色的插頭(或插座)相接。

各部位名稱




- ① 開門掣
- ② 照明燈
- ③門鉸
- 4) 門鎖
- ⑤裝有透明窗的爐門
- ⑥ 爐門密封襯墊和襯墊表層
- ⑦ 聯接器
- ⑧控制板
- ⑨波導管罩*

(*註:請勿試圖拆去波導管罩。)

- ⑩ 電源線
- ⑪通風口
- ⑫ 轉盤
- ③ 轉盤旋轉架
- 14 標牌

控制板



微波烹調技巧

食品的放置	較厚向外,較薄向内(中央)。
決定烹調時間	開始時先用較短之烹調時間,然後再根據烹調後的情況而追加時間。若烹調時間過度,會引起食物燒焦、起火。
食品的覆蓋	參考食譜的指南用耐微波保鮮紙、蓋或紙巾而把食品覆蓋好。這 樣可以防止汁液飛濺,以及幫助食物均匀烹調。
食品的局部遮蓋	以防止肉塊細薄部份烹調過度,解凍時應用鋁箔紙(錫紙)把這些部份 包好。
食品的攪拌	必要時於烹調過程中由外至内攪拌食物一至兩次。
食品的翻轉	烹調雞腿、漢堡或扒類時,時間過半翻轉之,以達均匀的烹調效果。
食品的重新放置	在烹調中途置換食品的位置,如外圍及中部食品的交換,以及上層和下層的交換,以達均匀烹調的效果。
食品的擱置	烹調之後,應擱置一段適當時間。若有可能,應將食物由爐中取 出並攪拌。擱置時加蓋,可讓食物不致烹調過度。
熟度檢查	烹調後食品之顏色及軟硬,可作為測試其生熟程度,方法如下: - 整個食品是否都有蒸氣逸出,而非只是局部或邊沿。 - 家禽關節部是否容易撕開。 - 肉塊或家禽已無血可見。 - 魚肉色已變,且可用刀叉輕易撕碎。
濕氣的凝聚	濕氣凝聚是微波爐烹調的正常現象。烹調中,食物内部的水份和 濕氣受熱蒸發。使爐箱内的含水量增加。一般來說,加蓋的食物 比不加蓋的食物所凝聚的濕氣較少。故應經常保持微波爐通風口 暢通無阻。
微波用煎碟	採用煎碟或可加熱之質料用具時,應先用一耐熱絕緣體如陶瓷碟 把煎碟與轉盤分隔,以冤轉盤、轉盤旋轉架以及聯接器受熱過度 而爆裂。而煎碟之加熱時間也不應超過指定的範圍。
微波爐用保鮮紙	烹調多油的食物時,由於保鮮紙有溶化之可能,故不可讓其和食物表面接觸。
微波爐用塑膠廚具	有些微波爐用的塑膠廚具不宜用來烹調多油或多糖的食物。

控制板指南

微波爐烹調時間最長可預設至三十分鐘。輸入的烹調時間增加單位由15秒至5分鐘不等,視乎用戶的烹調時間總數而定(見下表)。

烹調時間	增加單位
0-1分鐘	15秒
1-4分鐘	30秒
4-15分鐘	1分鐘
15-30分鐘	5分鐘

	烹	調	解凍		
1.	假定閣下想用中火(MED)烹調10分鐘。		假定閣下想為0.5公斤的雪藏肉塊解凍。		
	選定所需微波烹調強度 為中(MED)。	Ф MED -	選定解凍(中低)的微波強度。	*中低 MED LOW	
2.	旋轉旋光定時器至適當 的烹調時間位置(刻度 10)。	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	旋轉旋光定時器至肉類 重量(0.5公斤)位置。	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	
	微波爐會自動啓動。烹調時間以閃動方式顯示並逐步遞減。				
3.	. 烹調時間倒數至"0"時您會聽到響聲,微波爐也會自動關閉電源。若要在烹調時間完結前停止烹調,請將旋鈕撥回"0"位置,或把微波爐門打開。 每次爐門打開,微波爐之操作都會立即停止。				

注 意

- 1.本微波爐設有安全裝置。如旋光定時器停留在"0"位置超過3分鐘,閣下必須重開爐門才可開始使
- 2.在肉類解凍指南上重量的刻度為專用於雪藏肉類的解凍而設。詳情請參考烹飪書專欄第②頁之解凍項目一覽表。

解凍其他食品時,選擇解凍設定及旋轉旋光定時器至適當的時間。

- 3. 烹調過程中,無論何時,均可打開爐門。如果閣下欲繼續烹調,把爐門再關上即可。
- 4. 若在烹調進行中想改變烹調火力或時間,可隨時轉動多段烹調控制或旋光定時器至所希望的設定即可。

示範功能(兒童安全鎖)

本功能主要供零售商店使用,同時亦可讓用戶練習旋鈕運作。

* 若要設定示範模式。

- 1. 打開爐門。
- 2. 向左邊旋轉旋光定時器,直至微波爐發出響聲。
- 3. 關上爐門。示範模式現已設定。

請在15秒内執行上述步驟。

注意

- 1. 在示範模式進行時,旋光定時器會閃動。
- 2. 微波爐可在沒有啓動微波能源的情況下示範烹調操作,並能以60倍的速度倒數至0。
- 3. 若要取消示範模式: 拔除微波爐的插頭:或執行上述步驟1至3。
- 4. 由於示範功能進行時是沒有微波能源輸出的,故用戶亦可用來鎖上控制板(作為兒童安全鎖的功能)。

清洗及注意事項

清洗前先拔去電源插頭或在清洗時把爐門打開,以防止微波爐啓動。

定時清洗微波爐 - 常保持微波爐清潔,否則會導致微波爐表面變質,更大大減低微波爐的壽命,甚致會 造成危險 。

爐箱外殼:

爐箱外殼請用中性肥皀水來清洗。洗淨後用柔軟的濕布將其清洗並抹乾。 清潔時,請勿使用粗粒狀洗潔劑。

爐門:

經常用濕布抹拭爐門、透明窗兩面、爐門襯墊、襯墊表層及其四週,以清除油膩和渣滓等。不要使用磨 蝕性的清潔劑。

控制板:

用一微濕軟布抹拭軟鍵控制板。切勿刮洗或以化學清潔劑或過多之水份來清洗。

注意:

清洗時請小心勿使定時器旋鈕離開 "0" (終止)的位置,否則一關閉爐門即會開始烹調。

爐箱内壁

為確保衛生,應用溫水軟布來清洗內壁。使用完畢後,以微濕軟布擦拭波導管罩,以去除食物渣滓。微 波爐內積聚的食物殘渣可能會過熱並冒煙或燃燒起來。

切勿使用化學烤箱去污劑,研磨去污劑或粗粒狀洗滌劑洗刷微波爐。切勿向焗爐的任何部份,直接噴射 焗爐清潔劑。應注意避免用過多的水清洗。而清洗之後,必須用布把水份抹乾。

轉盤及轉盤旋轉架:

請用中性肥皀水來清洗,並徹底抹乾。

維修前的檢查

在維修之前請先作以下檢查:

將一杯水(約250毫升)放置於轉盤上,並把爐門關妥。 將定時器設定以高火烹調2分鐘。

Α.	照明燈是否點亮?	是	否
В.	通風扇是否轉動?(將手放在後方的通風口試探)	是	否
С.	轉盤是否旋轉?(轉盤可以順時針或逆時針旋轉)	是	否
D.	2分鐘後,是否發出訊號鈴聲?	是	否
Ε.	水是否已經變熱?	是	否

如果以上問題有一為"否",請檢查電源插座及保險絲。

檢查後,如果電源插座及保險絲均未出現毛病,而微波爐仍有問題,請立刻與聲寶維修中心聯絡。

注意:

- 1. 若旋光定時器不停閃動,而烹調時間也開始迅速倒數,表示微波爐正處於示範模式中。請參照第C-7頁了解詳情。
- 2. 如果在高火之狀態下烹調時間超過20分鐘,微波功率會自動降低以避免過熱。

規 格

交流電壓 :請參考微波爐背面標牌所示。

電力消耗 : 1.21干瓦

輸出功率 : 800瓦* (IEC測試程序) 微波頻率 : 2450MHz (乙類/第二組)**

外型尺寸 : 460毫米(闊) × 275毫米(高) × 353毫米(深) 爐箱尺寸 : 322毫米(闊) × 212毫米(高) × 336毫米(深)***

微波爐容量 : 23公升***

烹調均匀度 : 轉盤系統(直徑295毫米)

重量 : 約12干克

- * 此規格是以國際電工委員會(IEC)為標準。
- ** 此是以國際標準(International Standard)CISPR11中對工業、科技及醫學(ISM)儀器的分類 。
- *** 微波爐的内部容量是根據最大闊度、深度和高度而計算的。實際存放食品的容量稍少於此値。

Cookware and Utensil Guide

器具 Utensil	微波 Microwave	解凍 Defrost
玻璃(耐熱) Glassware (heat-resistant)		
陶瓷(耐熱) Ceramic (heat-resistant)		
瓷器,石器 Pottery, Stoneware		
金屬廚具 Metal Cookware	×	×
竹籮,籐器及木器 Straw, Wicker and Wood	短時間 Short time	×
塑膠廚具(微波耐用) Plastic Cookware (microwave-safe only)	短時間 Short time	×
紙碟,紙巾 Paper Plates/Towel	短時間 Short time	×
保鮮紙(微波耐用) Plastic Wrap (microwave-safe only)		×
鋁箔紙(錫紙) Aluminium Foil Paper	局部遮蓋 Shielding	局部遮蓋 Shielding
鋁/錫質盤 Aluminium Foil Dish	×	×

Rice Menu Chart

份 量 Quantity	烹調時間 Time	烹調火力 Power Level	作法 ● 將米淘洗乾淨。	Method • Wash rice until water
2人用 For 2 persons 150克米 150g rice 240毫升水 240ml water	15分鐘 15 min .	中高火 MED HIGH	● 將米和水共盛於一深底容器(約2至3公升),浸泡30分鐘。 ● 攪拌均匀後,加蓋進行	a deep casserole (2 ℓ to 3 ℓ) and soak for 30 mins.
4人用 For 4 persons 300克米 300g rice 480毫升水 480ml water	18分鐘 18 mi n.	中高火 MED HIGH	烹調。 ● 烹調完畢後,輕輕攪 拌,加蓋擱置5分鐘。	 Stir and cook with cover. After cooking, stir lightly and stand for 5 mins with cover.

- **注意** · 1兩約為38克。
 - ・烹調開始時的用水溫度以約20℃為標準。倘若烹調用水的溫度高於或低於20℃時,烹調的效果便不會很理想。
 - · 為了使容器在爐箱内順利地旋轉, 必須將容器放在轉盤中心位置上。
 - ·在此所說明的烹調方法為不加入其他材料的米飯。

- NOTE 1 tael = approx. 38 g
 - Water temperature should be about 20°C at the initial cooking. If it is more or less than 20°C, cooking result may not be ideal.
 - The casserole should be put in the center of the turntable to ensure that the casserole is turning well inside the oven.
 - Plain rice without any ingredients are instructed here.

Defrost Chart

項目 Menu	解凍時間 Defrost Time	烹調火力 Power Level		方法 Instruction	
冤治牛肉 Ground Beef	每500克 6分鐘 6 min. per 500g	中低火 MED LOW	置於淺碟上。 中途應取出已溶解的部位,而微 溫部份則用錫紙蓋好。 解凍結束後用錫紙包裹、擱置。	Place on a shallow dish. After half the time, take out defrosted beef. Then turn over and shield the warm portions as needed. After defrost time, stand covered with foil.	Standing Time 5~30分鐘 5 to 30 min.
牛骨排/ 牛扒 Beef Ribs/ Steaks	每500克 6分鐘 6 min. per 500g	中低火 MED LOW	置於淺碟上。 中途分開牛骨排/牛扒,重排位 置,已溶解的部位可用錫紙蓋好。 解凍結束後用錫紙包裹、擱置。	Place on a shallow dish. After half the time, separate, rearrange, and shield as needed. After defrost time, stand covered with foil.	5~30分鐘 5 to 30 min.
豬骨排/ 豬扒 Pork Ribs/ Chops	每500克 6分鐘 6 min. per 500g	中低火 MED LOW	置於淺碟上。 中途分開豬骨排/豬扒,重排位 置,已溶解的部位可用錫紙蓋好。 解凍結束後用錫紙包裹、擱置。	Place on a shallow dish. After half the time, separate, rearrange, and shield as needed. After defrost time, stand covered with foil.	5~30分鐘 5 to 30 min.
雞翼 Chicken Wings	每500克 6分鐘 6 min. per 500g	中低火 MED LOW	置於淺碟上。 中途分開雞翼,重排位置,已溶解的部位可用鍚紙蓋好。 解凍結束後用鍚紙包裹、擱置。	Place on a shallow dish. After half the time, separate, rearrange, and shield as needed. After defrost time, stand covered with foil.	5~30分鐘 5 to 30 min.
雞下脾 Drumsticks	每500克 6分鐘 6 min. per 500g	中低火 MED LOW	置於淺碟上。 中途分開雞下脾,重排位置,已 溶解的部位可用鍚紙蓋好。 解凍結束後用鍚紙包裹、擱置。	Place on a shallow dish. After half the time, separate, rearrange, and shield as needed. After defrost time, stand covered with foil.	15~30分鐘 15 to 30 min.
雞(全隻) Whole Chicken	每1干克 10分鐘 10 min. per 1.0kg	中低火 MED LOW	把雞胸向下放於淺碟上。 中途翻轉一次,已溶解的部位可 用錫紙蓋好。 解凍結束後用錫紙包裹、擱置。	Place breast side down on a shallow dish. After half the time, turn over and shield as needed. After defrost time, stand covered with foil.	20~45分鐘 20 to 45 min.

- │ 注意 │ · 在解凍之前,除去冷凍肉類之塑膠或紙包裝,之後放於耐微波淺碟上進行解凍。
 - · 當雪藏冤治牛肉時,應儘量把牛肉鋪平至一層。(厚度:不超過3厘米) 而雪藏雞肉、牛扒或豬扒時,也應分開而以單層式貯藏為佳。若需多層重疊,可用雪藏膠袋把層面分開,這樣 當解凍時,效果便會理想及容易。

- NOTE Remove plastic or paper wrap from frozen packaged meat before defrosting. Then place on a shallow dish for defrosting.
 - When freezing ground beef, shape it into flat even sizes. (Thickness: below 3 cm) For chicken pieces, steaks and chops freeze separately in single flat layer, and if necessary interleave with freezer plastic to separate layers. This will ensure even defrosting.

註 NOTE:

量度標準 Measure Standard

1 cup = 250 ml1 tsp. = 5 ml1杯 = 250毫升 1茶匙 = 5毫升 1湯匙 = 15毫升 1 tbsp. = 15 ml 1 tbsp. = 3 tsp. 1湯匙 = 3茶匙

食譜

RECIPES

湯類

鮮菇蝦丸湯

[材料]

蝦230克、肥肉40克、草菇1罐、蔥適量、麻油適量

〔調味料〕

(A)

鹽1茶匙、味精1/2茶匙、胡椒粉1/2茶匙、蛋白1 隻、生粉1/2茶匙

(B)

鹽1茶匙、米酒1湯匙、味精2茶匙、水3杯

〔作法〕

- 1. 蝦去腸,瀝乾水份後剁成茸,加肥肉及調味料 (A),拌成蝦膠,以湯匙做成蝦丸。
- 2. 於一較深的耐熱容器内放入調味料(B),附蓋用 微波高火加熱7分鐘。
- 3. 加入蝦丸、草菇及蔥,附蓋加熱3~4分鐘,直至 蝦丸浮起。吃時以麻油調味便可。

蕃茄肉丸湯

[材料]

蕃茄150克、 発治豬肉150克、蔥2條、薑2片、 莞茜(切碎)少許、芹菜(切碎)少許、麻油適量

〔調味料〕

(A)

鹽1/2茶匙、味精1/4茶匙、米酒1/2茶匙、醬油 1/2茶匙、生粉1茶匙、蛋白1隻

(B)

鹽1/2茶匙、蔥1條、胡椒粉1/4茶匙、味精1/4茶 匙

〔作法〕

- 1. 把蔥及薑切碎。把蕃茄切塊。
- 2. 將冤治豬肉、蔥、薑和調味料(A) 攪匀,再加入 蛋白及生粉調匀。用湯匙做成肉丸。
- 3. 於一較深的耐熱容器中加水3杯和蕃茄,附耐熱蓋用微波高火加熱7分鐘,加入肉丸及調味料(B) 拌匀,附蓋加熱3~4分鐘。飾以莞茜及芹菜。食用時,加入麻油調味。

SOUP

Shrimp Balls and Straw Mushroom Soup

[Ingredients]

230 g Shrimps 40 g Pork fat

1 can Straw mushrooms few Spring onions (strips)

few Sesame oil

[Seasonings]

(A)		(B)	
1 tsp	Salt	1 tsp	Salt
1/2 tsp	Monosodium	1 tbsp	Rice wine
	glutamate	2 tsp	Monosodium
1/2 tsp	Pepper		glutamate
1	Egg white	3 cups	Water
1/2 tsp	Cornflour		

[Method]

- 1. Remove veins from shrimps, drain and chop. Add pork fat and seasonings (A), stir well, to make a thick paste. Use a tablespoon to form shrimp balls. Set aside.
- 2. Combine seasonings (B) in large casserole. Cover and microwave at HIGH for 7 minutes.
- 3. Add shrimp balls, straw mushrooms and spring onions. Cover and microwave at HIGH for another 3 to 4 minutes until shrimp balls float. Sprinkle sesame oil in soup and serve.

Meatballs and Tomato Soup

[Ingredients]

150 g	Tomatoes	few	Coriander, chopped
150 g	Ground pork	few	Celery, chopped
2 stalks	Spring onion	few	Sesame oil
2 cliege	Cincor		

[Seasonings]

(A)	_	(B)	
1/2 tsp	Salt	1/2 tsp	Salt
1/4 tsp	Monosodium	1 stalk	Spring onion
	glutamate	1/4 tsp	Pepper
1/2 tsp	Rice wine	1/4 tsp	Monosodium
1/2 tsp	Soy sauce		glutamate
1 tsp	Cornstarch		
1	Egg white		

- Finely chop spring onion and ginger. Cut tomatoes into quarters.
- 2. Mix ground pork with spring onion, ginger and seasonings (A), then add egg white and cornstarch, stir well. Use tablespoon to form meatballs.
- 3. Microwave 3 cups water and tomatoes in a large, covered bowl at HIGH for 7 minutes. Add meat balls and seasonings (B), cover, microwave at HIGH for another 3 to 4 minutes. Garnish with coriander and celery, sprinkle sesame oil before serving.

魚茸西蘭花羹

[材料]

魚肉300克、西蘭花150克、火腿(切碎)2湯匙、 芹菜(切碎)1湯匙

〔調味料〕

(A)

蛋白1隻、鹽1/2茶匙、米酒1茶匙

(R)

米酒1茶匙、蔥1條、薑2片

(C)

鹽1/2茶匙、味精1/4茶匙、胡椒粉1/4茶匙

〔作法〕

- 1. 魚去骨並切成茸,加入調味料(A) 拌匀。
- 2. 洗淨西蘭花,並切小朶。放其於較深的耐熱容器 之内,加水2湯匙,附耐熱蓋用微波高火加熱2分 30秒鐘。
- 3. 於較深耐熱容器内加入水3杯及調味料(B) 拌匀, 附蓋用微波高火加熱7分鐘。加入調味料(C) 及西 蘭花,附蓋用微波高火再加熱2分30秒鐘。
- 4. 將魚茸加入湯内攪勻,附蓋用微波高火加熱1分鐘。取出,撒上火腿碎和芹菜碎即成。

洋蔥芝士湯

[材料]

多士1片、洋蔥75克(切條)、雜菜忌廉湯1罐

芝士配料

柏馬遜芝士10克、忌廉芝士30克、雪利酒半茶 匙、紅辣椒粉和胡椒粉少許

〔調味料〕

油1¹/2湯匙、月桂葉1/2片、百里香1/3茶匙、紅辣椒粉半茶匙、雪利酒1/4茶匙、鹽少許

〔作法〕

- 1. 洋蔥片放在耐熱容器中,加入調味料,附蓋以微 波高火加熱2分30秒鐘。
- 2.加入雜菜湯攪勻,附蓋以微波高火加熱5~6分 鐘。
- 3. 在多士上塗上攪匀的芝士配料,切成兩半。
- 4. 作好的湯倒入兩個碗内,上面飾以多士。

Broccoli and Minced Fish Soup

[Ingredients]

300 g Fish meat 150 g Broccoli 2 tbsp Ham, chopped 1 tbsp Celery, chopped

Ginger

[Seasonings]

(C) (A) 1/2 tsp Salt Egg white Monosodium 1/2 tspSalt 1/4 tspRice wine glutamate 1 tsp 1/4 tsp Pepper (B) 1 tsp Rice wine 1 stalk Spring onion

[Method]

2 slices

- Remove fish bones and finely chop fish meat. Add in seasonings (A), stir slightly.
- Rinse broccoli and cut into small pieces. Put it in casserole and add 2 tablespoons of water, then cover and microwave at HIGH for 2 minutes 30 seconds.
- In a casserole put in 3 cups of water and seasonings (B), stir well. Cover and microwave at HIGH for 7 minutes. Add seasonings (C) and broccoli. Microwave at HIGH for another 2 minutes 30 seconds.
- 4. Stir chopped fish mixture into boiling soup, cover and microwave at HIGH for 1 minute. Garnish with chopped ham and celery.

Onion Soup with Cheese Topping

[Ingredients]

1 slice Toast

75 g Onion, sliced

1 can Cream Vegetable Soup

Cheese topping

10g Parmesan cheese
30 g Cream cheese
1/2 tsp Sherry wine
dash Paprika and pepper

[Seasonings]

1 ½ tbsp Oil
1/2 pc Bay leaf
1/3 tsp Thyme
1/2 tsp Paprika
1/4 tsp Sherry wine
few Salt

- Add seasonings to sliced onion in an ovenproof casserole, cover, microwave on HIGH for 2 minutes 30 seconds.
- 2. Add in vegetable soup. Cover and microwave on HIGH for 5 to 6 minutes.
- Glaze the blended cheese topping onto toast and cut into halves.
- Pour the prepared soup into 2 serving soup bowls, then top it with glazed toast.

MEAT =

雞絲海蜇皮

〔材料〕

海蜇皮1 ³/5杯、青瓜1條(約50克)、雞腿肉230克、蔥10厘米(切末)、薑3片、酒1湯匙、蕃茄少許(裝飾)、芫茜少許(裝飾)

〔醬汁料〕

切碎蔥末3湯匙、切碎薑末1茶匙、醬油4湯匙、糖1/2茶匙、醋1湯匙、辣醬2湯匙、芝麻醬2湯匙

〔作法〕

- 1. 可用溫水浸泡海蜇皮過夜或2~3天,瀝乾切絲。
- 2.注入熱水,用叉或筷子攪動,直至其變曲,立即 加冷水浸其片刻,撈起瀝乾待用。
- 3. 青瓜切絲。
- 4. 雞腿肉塊較厚處用刀切開,用牙籤或竹籤於其表皮紮數孔。然後,使其整塊的雞皮面朝下放置於較深的耐熱容器之中,加入蔥、薑及酒,附耐熱蓋用微波高火加熱2分30秒。附蓋擱置,直至完全冷卻後,切其為絲。
- 5. 將2., 3. 及4. 適當擺設於一菜盤中。
- 6. 澆上拌匀的醬汁料。食用時攪匀即可。
- 7. 用蕃茄和芫茜裝飾點綴之。

長芥菜肉丸子

[材料]

瘦肉200克、冬菇10隻、薑2片、長芥菜300克、 油1湯匙、水800毫升、蘇打粉2茶匙

[調味料]

鹽1/2茶匙、味精1/4茶匙、生抽1/2茶匙、 麻油1/2茶匙、生粉1茶匙、胡椒粉少許

[醬汁料]

原湯300毫升、鹽1/2茶匙、味精1/2茶匙、糖1/2茶匙、生抽1茶匙、麻油1/2茶匙、生粉1湯匙、胡椒粉少許

〔作法〕

- 1. 把瘦肉與調味料混合,擠壓成丸子,附蓋以微波高火加熱1分30秒鐘。
- 2.除去長芥菜葉,切成塊狀。
- 3.注入800毫升水,加2茶匙蘇打粉,使之浸泡之後 瀝乾。
- 4. 芥菜、薑和冬菇放入深盤,澆上1湯匙油,附蓋 用微波高火加熱約4~5分鐘。中途攪拌均匀。
- 5. 把醬汁料拌匀,加蓋用微波高火加熱2分鐘。

Cold Chicken with Chili

[Ingredients]		[Sauce]	
1 ³ / ₅ cups	Jellyfish	3 tbsp	Green onion,
1 (50 g)	Cucumber		chopped
230 g	Chicken leg	1 tsp	Ginger, grated
10 cm	Green onion	4 tbsp	Soy sauce
3 slices	Ginger	1/2 tsp	Sugar
1 tbsp	Chinese wine	1 tbsp	Vinegar
few	Tomato	2 tbsp	Chili sauce
few	Parsley	2 tbsp	Sesame paste

[Method]

- 1. Soak jellyfish in lukewarm water overnight or for 2 to 3 days. Drain.
- Pour hot water over jellyfish and mix with fork or chopsticks. As soon as it shrivels, add cold water, soak for a while, and drain.
- 3. Shred cucumber.
- 4. Cut chicken legs, pierce the skin of each chicken leg with toothpick, and put them in casserole with skin facing down. Add green onion, ginger and wine, cover and microwave at HIGH for 2 minutes 30 seconds, let cool and then slice.
- 5. Place ingredients from 2, 3 and 4 on plate.
- 6. Pour over mixture of sauce. Mix well before serving.
- 7. Garnish with tomato and parsley.

Meatballs with Long Mustard Sauce

[Ingredients]		[Sauce]	
200 g	Pork, minced	300 ml	Stock
10	Mushrooms	1/2 tsp	Salt
2 slices	Ginger	1/2 tsp	Monosodium
300 g	Long mustard		glutamate
1 tbsp	Oil	1/2 tsp	Sugar
800 ml	Water	1 tsp	Light soy sauce
2 tsp	Bicarbonate of soda	1/2 tsp	Sesame oil
•		1 tbsp	Cornflour
		dash	Pepper

[Seasonings]

1/2 tsp Salt

1/4 tsp Monosodium glutamate

1/2 tsp Light soy sauce

1/2 tsp Sesame oil

1 tsp Cornflour

dash Pepper

- Mix minced pork with all seasonings. Make into balls and cover, microwave at HIGH for 1 minute 30 seconds.
- Cut away long mustard leaves and cut into decorative pieces.
- Soak in 800 ml water and add 2 tsp bicarbonate of soda. Drain.
- 4. Place mustard leaves, ginger and mushrooms in casserole, sprinkle 1 tbsp oil and cover, microwave for around 4 to 5 minutes at HIGH. Stir after half the
- Mix together sauce ingredients and cover, microwave at HIGH for 2 minutes.
- 6. Pour sauce over cooked ingredients and serve.

金珠肉丸

[材料]

冤治豬肉400克、蔥粒1湯匙、蒜粒1/2茶匙、雞蛋1隻、酒1湯匙、鹽1/2茶匙、醬油1湯匙、麻油1湯匙、 生粉2湯匙、麵粉2湯匙

〔表面用料〕

珍珠肉丸(11個): 糯米1/2杯、水100毫升 金肉丸子(11個): 雞蛋1隻、蛋黃1隻、鹽少許、水 2²/3湯匙

〔裝飾物〕

油炸豌豆120克、辣油少許、鹽及胡椒粉少許

〔作法〕

將材料混合拌匀。用茶匙將其作成大小相同的球形 肉丸(22個左右)。

珍珠肉丸(11個)

- 1. 用清水浸糯米3小時,撈出瀝乾。
- 2. 把肉丸滾粘糯米。
- 3. 置其於耐熱容器中,加入100毫升之水,附耐熱 蓋用微波高火加熱4~5分鐘。烹調過程中,觀察 其色味生熟程度。

金肉丸子(11個)

- 1. 把雞蛋,蛋黃和鹽攪匀。
- 2. 開鑊把全部蛋液煎至為大小適度的數張薄蛋皮。
- 3. 將蛋皮切絲,並撒於肉丸上。
- 4. 將金肉丸子及水放入耐熱容器中,附耐熱蓋用微 波高火加熱3~5分鐘。
- ※擺設於菜盤內,用油炸豌豆加以裝飾。淋上辣油,或鹽和胡椒粉,趁熱食用為佳。

Pearl and Gold Meatballs

[Ingredients]

400 g Ground Pork

1 tbsp Green onion, chopped

1/2 tsp Garlic, grated

1 Egg

1 tbsp Wine

1/2 tsp Salt

1 tbsp Soy sauce

1 tbsp Sesame oil

2 tbsp Cornflour

2 tbsp Flour

[Coating]

Pearl meatballs (11 pieces):

1/2 cup Glutinuous rice

100 ml Water

Gold meatballs (11 pieces):

 $\begin{array}{ll} 1 & Egg \\ 1 & Egg \ yolk \\ dash & Salt \\ 2 \, ^2/3 \ tbsp & Water \end{array}$

[Garnish]

120 g Snow peas, fried few Red pepper oil few Salt and pepper

[Method]

Mix ingredients well and form into small meatballs (approx. 22 pieces). Uniform-sized balls can be easily made by using a teaspoon.

Pearl meatballs (11 pieces)

- 1. Soak glutinuous rice in water for 3 hours and drain.
- 2. Roll meatballs in glutinuous rice.
- Place the meatballs and water of 100 ml in casserole, cover, microwave at HIGH for 4 to 5 minutes. Watch for doneness during cooking.

Gold meatballs (11 pieces)

- 1. Beat egg and egg yolk with a dash of salt.
- Grease skillet, heat and pour in enough egg mixture to thinly coat bottom of skillet. When egg sets, remove. Repeat this process until all the egg is used.
- 3. Shred egg sheets and sprinkle over meatballs.
- Place meatballs and water in casserole, cover, microwave at HIGH for 3 to 5 minutes.
- * Garnish with fried snow peas and serve hot with red pepper oil, or salt and pepper to taste.

水晶雞

[材料]

雞肉380克、豬皮150克、冬菇2隻、火腿8片、 芫茜少許、水100毫升

〔調味料〕

鹽1/2茶匙、米酒1茶匙、味精1/4茶匙

〔作法〕

- 1. 雞肉去骨洗淨,切成2厘米長的四方塊,以沸水煮去血水。豬皮的處理相同。
- 2. 耐熱容器内加調味料、雞肉、豬皮、一隻切粒的冬菇及100毫升水,附蓋用微波高火加熱約7~8分鐘。
- 3.取一大碗將火腿、冬菇及芫茜排成漂亮的圖案, 再把煮好的雞塊排置其上,倒入(2)後待涼。
- 4. 附蓋放入雪櫃冷藏約3小時至全部凝結後取出, 把碗反轉倒於平盤上便可供食用。

海鮮類 ————

釀蜆

[材料]

蜆8隻、免治豬肉40克、酒1茶匙、醬油1茶匙、 蔥粒1湯匙、雞蛋1/2隻(打好)、生粉1½湯匙、 薑汁1/4茶匙、鹽1/2茶匙、糖1/4茶匙

[作法]

- 1. 浸蜆於鹽水,以清洗其泥沙,讓其貝殼相互洗擦,以至完全洗淨。
- 2. 置蜆於一耐熱容器内加水70毫升,附耐熱蓋用微波高火加熱約3分鐘(或直至蜆貝殼張開)。
- 3. 將其餘材料混合拌匀,分為8等份。
- 4. 將各份分別填入空的蜆貝殼之中。
- 5. 將這16半蜆殼擺設於一耐熱大淺盤中,加水50毫升,附耐熱蓋用微波高火加熱約3~3分30秒鐘。 取出,趁熱食用為佳。

Crystalline Chicken

Coriander leaves

[Ingredients]		[Season	[Seasonings]	
380 g	Chicken meat	1/2 tsp	Salt	
150 g	Pork skin	1 tsp	Rice wine	
2	Mushrooms	1/4 tsp	Monosodium	
8 slices	Ham		glutamate	
100 ml	Water			

[Method]

few

- Remove bone from chicken meat, rinse and cut into 2 cm square pieces, blanch in boiled water to drain blood. Treat pork skin the same way.
- Combine seasonings, chicken meat, pork skin, 1 chopped mushroom, and 100 ml water in casserole. Cover and microwave at HIGH for around 7 to 8 minutes.
- 3. Use ham, mushroom and coriander leaves to create designs in a large bowl. Place boiled chicken meat on top, pour in (2) and let cool.
- 4. Cover and refrigerate for 3 hours until set. Turn upside down onto a flat plate and serve.

SEAFOOD =

Stuffed Clams

FT... - ... 12 - ... 4 - 1

[Ingredients]			
8	Clams	1/2	Egg, beaten
40 g	Ground pork	1 ¹ /2 tbsp	Cornflour
1 tsp	Wine	1/4 tsp	Ginger juice
1 tsp	Soy sauce	1/2 tsp	Salt
1 tbsp	Green onion,	1/4 tsp	Sugar
	chopped		

- Soak clams in salt water to remove sand. Clean clams thoroughly by rubbing shells against each other.
- Place clams in casserole, add 70 ml water, cover and microwave at HIGH for around 3 minutes (or until shells open).
- 3. Mix all other ingredients together and divide into 8 portions
- 4. Stuff each portion into each empty half-shell of clam.
- 5. Arrange all 16 half-shells on a platter, add 50 ml water and cover, microwave at HIGH for around 3 to 3 minutes 30 seconds. Serve hot.

檸汁魚鰈

[材料]

人造牛油或牛油1/2杯、麵粉2²/₃茶匙、新鮮檸檬汁2²/₃湯匙、切碎芫茜1湯匙、鹽1/4茶匙、胡椒粉少許、芹菜籽少許、鰈魚或比目魚片500克(新鮮或解凍)

〔作法〕

- 1. 把人造牛油置於長方形烤盤或25厘米的方形烤鍋内。用微波高火加熱1~2分鐘使其溶化,除魚以外,加入其他的材料混合攪匀成牛油醬。
- 2. 將牛油醬塗於鰈魚兩面,排列於燒盤上,包上保 鮮紙,用微波高火加熱7~8分鐘,直至魚中央用 叉能簡單分開為止。

宮保明蝦

[材料]

大蝦6隻(約200克)、蔥2條、辣椒8隻、酒3湯匙、 生粉1湯匙、薑2片、油1湯匙

(調味料)

醬油1 1/2湯匙、醋1湯匙、糖1湯匙

〔作法〕

- 1.把蝦去腸。保留其殼尾,每隻切成2~3段。置其 於一菜盤内,注酒於其上浸泡之。
- 2. 蔥切5厘米段,辣椒切半去籽。
- 3. 取出浸在酒中之蝦,然後粘上生粉。
- 4. 置蝦塊、蔥、辣椒以及薑於一較深的耐熱容器内,加入油1湯匙充分拌匀之,附耐熱蓋用微波高火加熱2分鐘。之後,取出攪拌。加入調味料,充分拌匀。附蓋用微波高火加熱2分鐘。
- 5. 取出攪拌。趁熱食用為佳。

Fillet of Sole in Lemon Parsley Butter

[Ingredients]

1/2 cup	Margarine or	few	Pepper
	butter	few	Celery seed
2 ² / ₃ tsp	Plain flour	500 g	Sole or flounder
2 ² / ₃ tbsp	Fresh lemon		fillets, fresh or
	juice		frozen, thawed
1 tbsp	Chopped parsley		
1/4 tsp	Salt		

[Method]

- 1. Place margarine in rectangular baking dish or 25 cm square casserole. Microwave at HIGH for 1 to 2 minutes until melted. Blend in remaining ingredients except fish fillets to make into butter sauce.
- Coat both sides of fish fillets with butter sauce. Arrange in the baking dish. Cover with plastic wrap. Microwave at HIGH for 7 to 8 minutes until fish flakes easily in centre with fork.

Prawns with Chili Peppers

[Seasonings] [Ingredients] 6 Prawns (about 200 g) 1 ¹/₂ tbsp Soy sauce 2 Vinegar Green onions 1 tbsp Chili peppers 1 tbsp Sugar 3 tbsp Wine Cornflour 1 tbsp 2 slices Ginger 1 tbsp Oil

- Clean prawns, slit the back and remove the vein. Cut each into two or three pieces, and place in bowl. Sprinkle with wine and leave to marinate.
- Cut green onion into 5 cm lengths. Halve chili peppers and remove seeds.
- 3. Remove prawns from wine, sprinkle with cornflour.
- 4. Place prawns, green onion, chili pepper and ginger in casserole, add 1 tablespoon oil and stir well. Cover and microwave at HIGH for 2 minutes. Take out and stir. Add seasonings, stir well. Cover and microwave at HIGH for 2 minutes.
- 5. Stir, serve hot.

清蒸魚

〔材料〕

魚1條(300~400克)、蔥1條、薑3片

〔調味料〕

酒2¹/2湯匙、醬油1¹/2湯匙、白胡椒粉1/4茶匙、 鹽1/2茶匙、糖1/2茶匙、油1湯匙、芫茜少許

〔作法〕

- 1. 刮去魚鱗,除去内臟,洗淨後,抹乾其水份,用 刀於魚身兩側別數處。
- 2. 把蔥切為兩條,把其中一條切半拍平,另一條則切粉。
- 3 將拍平的兩節蔥置於一耐熱碟上,再放數片薑 片。然後,置魚於其上。把攪勻調味料淋於魚 身,加水2湯匙,附耐熱蓋(或覆上保鮮紙),用 微波中高火加熱6~8分鐘。
- 4.加入熱的油1湯匙並澆於魚身上。食用時撒上蔥 粒和芫茜即可。

Steam Whole Fish

[Ingredients]

1 (300-400g) Fish

1 stalk Spring onion 3 slices Ginger

[Seasonings]

2 ½ tbsp Chinese wine 1 ½ tbsp Soy sauce 1/4 tsp White pepper

1/2 tsp Salt
1/2 tsp Sugar
1 tbsp Oil
few Parsley

[Method]

- Unscale fish, remove the intestines, clean and drain.
 Make few slashes on each side of fish.
- Take half of spring onion, cut into two parts and pat. Chop the remaining spring onion.
- 3. Place the patted spring onion in plate, add several slices ginger. Place fish on it. Top with mixed seasonings and 2 tablespoons of water. Cover and microwave at MED HIGH for 6 to 8 minutes.
- 4. Add 1 tablespoon of boiling oil on the fish. Decorate with chopped spring onion and parsley before serve.

蔬菜類

涼拌豆腐

[材料]

豆腐1塊(4磚)、免治豬肉或牛肉110克、 洋蔥粒1/4杯

〔調味料〕

豆瓣醬1湯匙、醬油1湯匙、麻油1/2湯匙、糖 $1^{1/2}$ 茶匙、 \times 50毫升、生粉1茶匙加水2茶匙調匀

〔作法〕

- 1. 置豆腐於耐熱容器内,用微波高火加熱1分鐘。 取出用水浸漂。撈起瀝乾,切塊,置於盤中。
- 2. 將肉和蔥盛入一耐熱容器內拌勻,附耐熱蓋用微波高火加熱3分鐘。時間至半時,攪拌一次。倒去溢出的汁液,然後,加豆瓣醬、醬油、麻油、糖及水於其中,充分拌勻。附蓋用微波高火再加熱約3分鐘。時間至半時,攪拌一次。烹調過程中,觀察其生熟程度。
- 3. 將生粉水注入其中,攪拌之,不附蓋用微波高火 再加熱40秒~1分鐘。
- 4. 煮好後澆於豆腐上。然後用生菜,蔥絲及車厘子 加以擺設修飾即可。

VEGETABLES

Cold Bean Curd

[Ingredients]

1 block Bean curd 110 g Ground pork or ground beef

ground beef 1/4 cup Onion, chopped

[Seasonings] 1 tbsp Bean paste

1 tbsp Soy sauce
1/2 tbsp Sesame oil
1 1/2 tsp Sugar
50 ml Water

1 tsp Cornflour mixed with 2 tsp water

- Place bean curd in casserole, microwave at HIGH for 1 minute. Remove and soak in water. Drain and cut into pieces. Arrange on serving plate.
- 2. Place meat and chopped onion in casserole, cover and microwave at HIGH for 3 minutes. Stir well after half the time, and remove excess oil. Add bean paste, soy sauce, sesame oil, sugar and water, stir well. Cover with the lid, microwave at HIGH for around 3 minutes, stir well after half the time. Check the color and doneness while cooking.
- 3. Pour in the cornflour mixture and stir. Uncover and microwave at HIGH for another 40 seconds to 1 minute.
- 4. Top bean curd with meat mixture. Garnish with lettuce, shredded green onion and cherries.

肉餡馬鈴薯

[材料]

馬鈴薯3個(大約600克)、洋蔥粒150克、 冤治豬肉100克、豌豆50克、油1茶匙

[調味料]

鹽1茶匙、牛油20克

〔作法〕

- 1. 洗淨馬鈴薯,擦乾其表面。用叉或針於其表皮刺 數孔,以讓蒸氣溢出。
- 置馬鈴薯於轉盤,用微波高火加熱8~9分鐘。加熱時間過半時,將其翻轉。完成後,用鋁箔紙包裹,擱置待用。
- 3. 取一較深的耐熱容器,加入洋蔥粒和1茶匙油拌 匀之,附耐熱蓋用微波高火加熱2~3分鐘。中途 攪拌一次。烹調過程中,觀察其生熟程度。
- 4.加入免治豬肉、豌豆和鹽,拌匀之,附蓋用微波 高火加熱2分鐘。加熱時間過半時,攪拌一次。
- 5. 把馬鈴薯頂端切開,挖空其内部。
- 6. 將(4)之肉餡填入其中,再從(5) 挖出之馬鈴薯蓋 封。
- 7. 於馬鈴薯表面塗滿牛油。置其於一耐熱淺盤中,用微波高火再加熱2分30秒~3分鐘。取出趁熱食用為佳。

燴素菜盤

[材料]

罐頭小竹筍30克、小蕃茄6個、磨菇6個、罐頭小玉米筍6條、罐頭草菇6隻、青菜230克、緑蘆筍14隻(切半)、胡蘿蔔1個(切片裝飾用)、馬鈴薯3片、白果1/2罐、鹽1½茶匙、煮菜用上湯800毫升、

上湯300毫升攪入生粉11/2湯匙、熟油適量

〔作法〕

- 1. 蔬菜洗淨放入爐内加鹽及上湯,分別用微波高火加熱1分30秒~2分鐘。
- 2. 每次煮完的上湯都倒掉。
- 3. 將蕃茄泡在沸水中,去皮。
- 4. 將各種蔬菜在盤中排成七彩形狀。
- 5. 將巳混有生粉的上湯,用微波高火加熱2~2分30 秒鐘,真至適量的程度,然後便可倒在蔬菜上。 淋上熟油即可食用。

註:可以隨意添加蔬菜種類。

Stuffed Potatoes with Mince Meat

[Ingredients]

[Seasonings]

Potatoes (about 600 g)

1 tsp Salt 20 g Butter

150 g Onion, minced 100 g Ground pork 50 g Green peas

1 tsp Oil

[Method]

- Wash potatoes and drain. Pierce the skin of each potato with a fork or skewer to allow steam to escape.
- 2. Place potatoes on the turntable, microwave at HIGH for 8 to 9 minutes, turn over after half the time. When done, cover with foil and set aside.
- Place minced onion and 1 teaspoon of oil in casserole, stir well. Cover and microwave at HIGH for 2 to 3 minutes. Stir after half the time. Check the color and doneness while cooking.
- 4. Stir in ground pork, green peas and salt, cover and microwave at HIGH for 2 minutes. Stir after half the cooking time.
- 5. Cut out the potatoes from the top, then hollow out potatoes with a spoon.
- 6. Stuff potatoes with mixture from (4) and cover openings with potato pieces taken out from (5).
- Glaze thoroughly with butter. Place on a plate and microwave at HIGH for 2 minutes 30 seconds to 3 minutes. Serve hot.

Vegetable Platter

[Ingredients]

r	carcinoj		
30 g	Baby bamboo	1	Carrot (sliced
	shoots, canned		for decoration)
6	Cherry tomatoes	3 slices	Potato
6	Champignon	1/2 can	Ginko nuts
	mushrooms	1 ¹ / ₂ tsp	Salt
6	Baby cornshoots,	800 ml	Vegetable stock
	canned	300 ml	Stock mix with
6	Straw mushrooms,		1 ¹ /2 tbsp
	canned		cornstarch
230 g	Green vegetable	few	Cooked oil
14	Green asparagus,		

[Method]

cut in half

- Clean all the vegetables. Place in casserole with salt and stock and microwave at HIGH for 1 minute 30 seconds to 2 minutes for each kind.
- 2. Discard the stock each time.
- 3. Dip tomatoes in boiling water; remove skin.
- 4. Arrange vegetables colorfully on plate.
- 5. Heat 300 ml of cornstarch mix in microwave at HIGH for 2 to 2 minutes 30 seconds until thicken. Pour over vegetables, sprinkle cooked oil on top and serve.

Note: Types of vegetables can vary or adjust according to personal taste.

[材料]

蘑菇7克(浸軟切半)、大蝦60克(去殼、去腸)、 魚餅20克(斜切)、雞胸肉80克(切丁)、 冷原湯400毫升、雞蛋4隻、生抽1/2湯匙、 鹽1/2茶匙、甜米酒2茶匙、芫茜1棵

〔作法〕

- 1. 將原湯、生抽、鹽、甜米酒和雞蛋混合在一起, 輕輕攪勻。
- 2. 將雞丁、魚餅、蘑菇和大蝦混合平均放入4隻碗内。
- 3. 將篩過的混合料(1)注入作好的材料(2)中。
- 4. 用茶匙取去混合料表面上的泡沫。
- 5.用鋁箔封住碗,在中心刺一個孔。用微波中火加熱7~9分鐘。

註:確認鋁箔沒有與轉盤或爐壁接觸。

- 6. 擱置5分鐘。
- 7. 飾以芫茜。

荷包蛋

[材料]

雞蛋4隻、油少量(塗抹用)

〔作法〕

- 1. 取數個小而深的耐熱容器 (例如盛湯用小盤之類的容器等),薄抹油於其內壁。然後,於每個容器中分別打入一隻雞蛋。
- 2.用竹籤於蛋黃處弄破2~3個小孔,以防其受熱膨脹而噴濺。
- 3. 將打有雞蛋的容器,圍一圓周於轉盤之上,覆蓋 上保鮮紙,用微波中低火加熱8~10分鐘即成。

數量	烹調時間(微波中低火)
1隻	1'30"~2'30"
2 隻	3'~4'
3 隻	5'~7'

- ※另外,因雞蛋大小鮮嫩程度而異,烹調所需時間 有所變化。因此,在加熱過程中,請適當地觀察 烹調情況。
- ※烹調1隻荷包蛋時,置其於轉盤之中央。

註:請注意避免過熱,以免引起噴濺。

EGGS =

Chawanmushi (Japanese Steam Eggs)

[Ingredients]

7 g	Mushrooms,	400 ml	Cold dashi
	soaked, cut into		soup
	halves	4	Eggs
60 g	Prawns, shelled	1/2 tbsp	Light soy sauce
	and deveined	1/2 tsp	Salt
20 g	Fish cake, cut at	2 tsp	"Mirin" (sweet
	an angle		cooking wine)
80 g	Chicken breast,	1 stalk	Parsley
	cut into cubes		

[Method]

- Blend dashi soup, light soy sauce, salt, Mirin, and eggs; beat lightly.
- Arrange chicken cubes, fish cake, mushrooms and prawns into 4 mug-like serving bowls.
- 3. Strain beaten mixture from (1) into (2).
- 4. Use a teaspoon to scoop excess bubbles from the surface of mixture.
- Cover the bowls with aluminium foil, prick a hole in the center and microwave on MED for 7 to 9 minutes. Note: Make sure that the foil do not touch each other, the turntable or the oven wall.
- 6. Let it stand for 5 minutes.
- 7. Garnish with parsley.

Poached Eggs

[Ingredients]

4 Eggs few Oil

[Method]

- Prepare a couple of small deep-bottomed heat resistant cooking dishes (such as small soup bowls). Have the inside of the dishes oiled thinly and break the eggs into one of each dish.
- 2. To prevent the eggs in the dishes from bursting while they are being heated, prick 2 to 3 holes in the yolks in advance using a toothpick or the like.
- Place the dishes on the turntable in a circle, cover each
 of them with a cooking wrap, and microwave on MED
 LOW for 8 to 10 minutes.

Quantity	Cooking Time (MED LOW Power)
1 Egg	1'30" to 2'30"
2 Eggs	3' to 4'
3 Eggs	5' to 7'

- * The cooking time may vary depending on the size or freshness of the eggs; adjust the cooking time by carefully watching how they are being cooked in the oven
- * When cooking one poached egg, place the dish in the middle of the turntable.

Note

Be careful not to overheat eggs; they may burst.

炒蛋

[材料]

雞蛋1隻、牛奶1湯匙

〔調味料〕

鹽少量、胡椒粉少量

〔作法〕

- 1.打蛋於一耐熱烹調杯內,加入牛奶、鹽和胡椒粉,充份拌匀之。置其於微波爐轉盤中,不附蓋用微波高火加熱40秒~1分鐘。
- 2. 之後,攪拌弄碎。

甜品類 ______

杏仁豆腐

[材料]

魚膠粉2湯匙、水600毫升、杏仁香精3/4湯匙、牛奶200毫升、罐裝雜果(連糖汁)適量

〔作法〕

- 1. 把魚膠粉盛入一較深的耐熱容器中,注水600毫升,附耐熱蓋用微波高火加熱7~9分鐘,待其完全溶解。之後,取出攪拌之。
- 2. 加入杏仁香精和牛奶, 充分攪拌之。
- 3. 盛其於一大碗,再放入雪櫃内待成形冷卻。
- 4. 取出切其為鑽石形。加以雜果及糖汁便可。

蒸葡萄乾蛋糕

[材料]

麵粉90克、雞蛋3隻、白糖70克、葡萄乾50克

[作法]

- 1. 把麵粉篩好,擱置一邊備用。
- 2. 取一較大的容器,於其中攪拌蛋白直至成形。
- 3.逐漸加糖於其中,攪匀之。
- 4. 將蛋黃加入,攪拌至發泡狀態。
- 5. 篩好的麵粉加入其中,與調好的蛋液快速攪匀。
- 6. 加入葡萄乾, 攪匀。
- 7. 取圓形或四邊形的耐熱點心烘烤容器,於其內側 塗上薄油層。然後,注入調好的麵粉混合料,弄 平其表面。覆蓋一紙巾,用微波高火加熱3~4分 鐘直至中央部份熟透。

Scrambled Eggs

[Ingredients] [Seasonings]

1 Egg pinch Salt

1 tbsp Milk pinch Pepper

[Method]

- Break the egg, put it into a heat-resistant cooking dish together with the milk, salt and pepper, and stir them well enough. Then place the dish in the middle of the turntable of the microwave oven, and cook, uncovered, on microwave HIGH for 40 seconds to 1 minute.
- 2. Stir the heated egg to small pieces.

DESSERTS ====

Almond Bean Curd

[Ingredients]

2 tbsp Gelatin 600 ml Water 200 ml Milk

3/4 tbsp Almond extract

few Canned mixed fruits (with syrup)

[Method]

- Put gelatin into casserole, add 600 ml water, cover and microwave at HIGH for 7 to 9 minutes, and stir until it dissolves completely.
- 2. Add milk and almond extract and stir well.
- 3. Pour into bowl, allow to set, and cool in refrigerator.
- 4. Cut into diamond shapes, garnish with mixed fruits and syrup.

Steam Raisin Cake

[Ingredients]

90 g Flour 3 Eggs 70 g White sugar 50 g Raisins

- 1. Sift flour well and set aside.
- 2. Beat egg white in bowl until soft peaks form.
- 3. Gradually add sugar, continue beating.
- 4. Combine yolks and beaten egg white.
- 5. Add flour and stir quickly.
- 6. Add raisins and stir.
- Pour the mixture into a well greased mold. Cover with a paper towel and microwave at HIGH for 3 to 4 minutes until the center part is cooked.

紅彩變幻

[材料]

碎酒晶粒1包、熱水1 ½杯、吉士粉5 ⅓湯匙、牛奶375毫升、砂糖1/2杯、吃呢拿香精1茶匙、打泡忌廉1杯、杏仁餅乾12塊、葡萄酒蛋糕1個、雪利酒1/2杯、草莓及青莓適量

〔作法〕

- 1. 用熱水把砵酒晶粒溶化。之後冷卻至半凝結狀態。
- 2. 吉士粉和牛奶攪勻,加入砂糖、香精,用微波高火加熱4~6分鐘。加熱途中攪拌2次,之後待冷卻。
- 3. 把一半之打泡忌廉鋪於其上。
- 4. 把杏仁餅乾和蛋糕放入4個盛器内,注上1/2雪利酒,把草莓和青莓夾層放入以上混合物。
- 5.重疊成層,冷卻2~3小時。
- 6. 把剩餘的打泡忌廉點綴表面。

蛋糊焦糖

〔材料〕

焦糖:

砂糖6湯匙

熱水2湯匙

牛奶蛋糊:

雞蛋3隻

砂糖1 1/2湯匙

牛奶450毫升

〔作法〕

- 1. 布甸盤内加入水和砂糖攪匀做成焦糖。
- 2. 用微波高火加熱3~4分鐘,或至焦糖變為深黃 色。
- 3. 放入4隻布甸盤内,擱置一邊。
- 4.輕輕攪拌蛋和砂糖,再加入牛奶攪匀。
- 5. 將攪拌好的牛奶蛋糊倒入布甸盤内,再置於大盤 上。
- 6. 將熱水注入大盤内使其與牛奶蛋糊呈同樣高度。
- 7. 用微波中火加熱15~18分鐘,直至成形。冷卻後即可進食。

Trifle

[Ingredients]

1 packet Port wine jelly crystals

1 ¹/₂ cups Boiling water 5 ¹/₃ tbsp Custard powder

375 ml Milk 1/2 cup Sugar

1 tsp Vanilla essence
1 cup Whipped cream
12 Macaroons
1 Madeira cake
1/2 cup Sherry Wine
few Strawberries
few Blueberries

[Method]

- Dissolve jelly crystals in boiling water. Refrigerate until partially set.
- Blend custard powder with milk; add sugar and vanilla essence. Cook on microwave HIGH for 4 to 6 minutes, stirring twice during cooking. Cool.
- 3. Fold half the whipped cream into custard.
- Arrange macaroons and cake in the base of 4 individual serving dishes. Pour half the sherry wine over macaroons and cake. Top with a layer of strawberries, blueberries, jelly and custard.
- 5. Repeat layers. Chill for 2 to 3 hours.
- 6. Decorate with remaining whipped cream.

Creme Caramel

[Ingredients]

Caramel:

6 tbsp Sugar 2 tbsp Hot water

Custard:

 $\begin{array}{ccc} 3 & Eggs \\ 1 \ ^{1}\!/_{2} \ tbsp & Sugar \\ 450 \ ml & Milk \end{array}$

- 1. Mix the sugar and water for caramel in a pudding basin.
- 2. Cook on microwave HIGH for 3 to 4 minutes, or until the caramel turns dark golden brown.
- 3. Pour into 4 ramekin dishes. Set aside.
- 4. Lightly whisk together eggs and sugar, stir in milk.
- 5. Pour the mixture into the ramekin dishes. Place ramekins in a large dish.
- Pour almost boiling water into the dish to reach the level of the custard.
- 7. Cook on microwave MED for 15 to 18 minutes until set. Chill before turning out and serve.

草莓醬

[材料]

草莓450克、檸檬汁1湯匙、砂糖350克

〔作法〕

- 1. 去掉草莓蒂,洗净。把草莓及檸檬汁放入約3公升容器内攪勻。
- 2. 用微波高火加熱4~5分鐘,至草莓變軟,再加入砂糖,混合調匀。
- 3. 用微波高火加熱12~14分鐘,使其至適當程度取出。
- 4. 冷卻後,放入儲存瓶内上蓋。約可作成0.5公斤 草莓醬。

梅子醬

[材料]

梅子900克(去核切成2等份)、水300毫升、 檸檬汁1湯匙、砂糖900克

〔作法〕

- 1.大碗内放入水和梅子,用微波高火加熱9~10分鐘,至梅子變軟。
- 2.加入檸檬汁和砂糖,攪拌使砂糖溶化,用微波高 火加熱20~23分鐘,待煮沸至適當程度取出。
- 3. 冷卻後,放入儲存瓶内上蓋。約可作成1.5公斤 梅子醬。

Strawberry Jam

[Ingredients]

450 g Strawberries 1 tbsp Lemon juice 350 g Sugar

[Method]

- 1. Wash and hull strawberries. Put strawberries and lemon juice into a 3 litre casserole, mix well.
- 2. Cook on microwave HIGH for 4 to 5 minutes, or until fruit is soft. Add sugar and stir well.
- Cook on microwave HIGH for 12 to 14 minutes, or until setting point is reached.
- 4. Cool slightly before putting in preserving bottle and cover. Makes approx. 1/2 kg of jam.

Plum Jam

[Ingredients]

900 g Plums, halved and unstoned

300 ml Water 1 tbsp Lemon juice 900 g Castor sugar

- Place plums and water in a large bowl. Cook on microwave HIGH for 9 to 10 minutes or until fruit is soft.
- Add lemon juice and sugar, stir until sugar dissolved. Bring to boil and cook on microwave HIGH for 20 to 23 minutes until setting point is reached.
- 3. Allow to cool slightly before putting in preserving bottle, then cover. Makes approx. 1 ½ kg of jam.

